



Motorcycle crane for JMP Lux 500/700 EH lift

Assembly instruction

Parts list:

- Lower u-section guide rail
- Upper flat bar section guide rail
- Crane body incl. guide rollers
- 4 x Allen screws (lower guide rail)
- 2 x countersunk screws (upper guide rail)
- 3 x hexagonal screws (upper guide rail)
- 3 x washers (upper guide rail)
- 5 x spacers (upper guide rail)

Assembly is realised on the right-hand side of the lift (in the direction of travel).
Fixing holes are provided.

Holes need to be drilled on site in first-series lifts.

Assembly:

- Remove the tool tray on the right (the screws are no longer required).
- Fit the lower guide rail (U-section) by inserting the 4 Allen screws into the pre-drilled holes. Please ensure that the holes at both ends of the guide rail are facing upwards.
- Then fit the upper guide rail (flat bar section) into the holes provided in the tool tray. Ensure here that the 90° countersink for the inner screws is facing outwards.
- Both the outer and the middle screw fittings are realised from the inside. Use the spacer with the larger inner diameter here.
- The two inner countersunk screws are fitted from the outside. The spacer with the smaller inner diameter should be used here.
- Then push the crane body into the two rails from the side (two people are need for this purpose).
- Secure on the right and left with a 6 mm screw to ensure the crane remains in the rail.
- The crane can then be slid along the entire length of the lift.